






CABLE, FREEZER DOOR  
PN - 19100081A



CABLE, UP / DOWN  
PN - 19500480A



COMPUTER BOARD  
PN - 19300527A



DEADWEIGHT ASSEMBLY  
PN - 19510119A




DIGITAL DISPLAY BOARD  
(AFTER SN-8018)  
PN - 1919300521A



GEAR W/ HOLE  
PN - 19500406A



HEALTH SWITCH ASSY  
PN – 19610510A




KEYPAD INSERT  
PN – 19300571A




MENU HOLDER, 12-CARD  
PN – 19380127A



MOTOR 115V  
PN – 19900555A



OPTO ENCODER DISK  
PN – 19500492A



OPTO ENCODER DISK/GEAR  
PN – 19510153A



OPTO ENCODER DISK/REEL  
PN – 19510117A



OPTO ENCODER SWITCH  
PN – 19500582A



PICKER TUBE ASSEMBLY  
PN – 19510113A



POWER BOARD  
PN – 19300530A



REED SWITCH, MAGNETIC  
PN – 19900518A




REED SWITCH, UP/DOWN  
PN – 19500515A





RIBBON CABLE  
PN – 19510300A



SLACK SWITCH  
PN – 1919500566A



THERMOMETER  
PN – 19600738A



THERMOSTAT  
PN – 19600513A



VACUUM PRESSURE SWITCH  
38" (TOP)  
PN – 19500557A



VACUUM PRESSURE SWITCH  
48" (BOTTOM)  
PN – 19200558A